



SUBURBAN MODELS SF & SH
MAKE SURE TO REMOVE FURNACE ACCESS PANEL
BEFORE INSTALLING CHEAPHEAT ADD-ON CABINET